



Original	Sustituto
 Power	 Power
 Freeze	 Freeze / Timer
 Hide	 Shift + Source
 Aspect/Ratio	 Eco / Aspect
 Resync	 Shift + Power
 Source	 Source
 Zoom	 + / Play
 Back	 Shift + Menu
 Enter	 Enter
 Up	 Up
 Down	 Down
 Left	 Left
 Right	 Right
 Menu	 Menu
 Vol+	 Vol + / Page +
 Vol-	 Vol - / Page -
 e	 Auto

Original	Sustituto
 Page Up	 Shift + Vol + / Page +
 Page Down	 Shift + Vol - / Page -
 1/Left	 Shift + Left
 2/Play/Pause	 Shift + + / Play
 3/Stop	 - / Stop
 4/VGA	 Help / Info
 5/Component	 3D / Invert
 6/Video	 Comp / Video
 7/SD/USB A	 Shift + Comp / Video
 8/HDMI/DVI	 Shift + Eco / Aspect
 9/LAN/WIFI	 Volt / Focus
 0/USB B	 Shift + 3D /
 >>I	 Shift + Up
 S-Video	 Mode

