



| Original  |                 | Sustituto   |                             | Original  |             | Sustituto   |                  |
|---|-----------------|---|-----------------------------|---|-------------|---|------------------|
|    | Index           |    | Play / Slow                 |    | 6           |    | 6                |
|    | Red / -1        |    | Red / Netflix / Search      |    | Contrast-   |    | << / Tune-       |
|    | Green / Timer / |    | Green / APP / Repeat        |    | Contrast+   |    | >> / Tune+       |
|    | Yellow / Stop   |    | Yellow / YouTube / Repeat   |    | 7           |    | 7                |
|    | Blue / Reveal   |    | Blue / Prime Video / Random |    | 8           |    | 8                |
|    | [≡]]]           |    | Rec / Rec Mode              |    | 9           |    | 9                |
|    | Cancel          |    | Exit / Cancel / Clear       |    | Brightness- |    | I<< / Preset-    |
|    | Size            |    | Zoom / Size                 |    | Brightness+ |    | >>I / Preset+    |
|    | TV              |    | TV/Radio /                  |    | P/C         |    | Back / Return    |
|    | Text            |    | Text / Goto                 |    | 0           |    | 0                |
|   | 1               |   | 1                           |   | AV          |   | AV / Input / RDS |
|  | 2               |  | 2                           |  | ←•→         |  | Display / Media  |
|  | 3               |  | 3                           |  | *\*         |  | Smart / List     |
|  | Tint-           |  | Shift + Left                |  | PIP         |  | Picture / Format |
|  | Tint+           |  | Shift + Right               |  | i           |  | Info / Angle     |
|  | 4               |  | 4                           |  | i           |  | Menu / Home      |
|  | 5               |  | 5                           |  | ----        |  | Subtitle / EQ    |









| Original | Sustituto                   | Original | Sustituto        |
|----------|-----------------------------|----------|------------------|
| -1       | Red / Netflix / Search      | *+       | >>  / Preset+    |
| +1       | Green / APP / Repeat        | P/C      | Back / Return    |
| STOP     | Yellow / YouTube / Repeat   | 0        | 0                |
| E7       | Blue / Prime Video / Random | PIP      | Picture / Format |
| E8       | Text / Goto                 | i        | Info / Angle     |
| 1        | 1                           | P+       | CH+ / Page+      |
| 2        | 2                           | Up       | Up               |
| 3        | 3                           | Mute     | Mute / Dimmer    |
| 4        | 4                           | Left     | Left             |
| 5        | 5                           | Vol-     | Vol-             |
| 6        | 6                           | OK       | OK               |
| -0       | << / Tune-                  | Right    | Right            |
| 0+       | >> / Tune+                  | Vol+     | Vol+             |
| 7        | 7                           | AUX      | Shift + 7        |
| 8        | 8                           | P-       | CH- / Page-      |
| 9        | 9                           | Down     | Down             |
| -*       | << / Preset-                | Power    | Power            |

