





































Original	Sustituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 Blue / Scan	 Blue / Prime Video / Random
 4	 4
 5	 5
 6	 6
 Yellow / ATS	 Yellow / YouTube / Repeat
 7	 7
 8	 8
 9	 9
 Green / Timer	 Green / APP / Repeat
 Green / Timer	 Sleep / Timer
 Speaker	 Setup / OPT /
 0 / AV	 0
 Audio	 Audio / Lang I/II

Original	Sustituto
 Red / AKTUELL	 Red / Netflix / Search
 OK	 OK
 Up / P+	 Up
 Up / P+	 CH+ / Page+
 Text / TV	 Text / Goto
 Left / Vol-	 Left
 Left / Vol-	 Vol-
 Right / Vol+	 Right
 Right / Vol+	 Vol+
 Menue / P/C	 Menu / Home
 Down / P-	 Down
 Down / P-	 CH- / Page-
 i	 Info / Angle
 Contrast-	 << / Tune-
 Contrast+	 >> / Tune+
 PIP	 Smart / List
 AUX	 Shift + 7



