



Original	Sustituto
[+]/Auto PC	Auto
Standby	Power
Menu	Menu
Shutter	Source
Lens Shift	Shift + Power
ADJ/Image ADJ.	Eco / Aspect
Up	Up
Down	Down
Left	Left
Right	Right
Select	Enter
Zoom +	Vol + / Page +
Focus +	+ / Play
Input 1	Shift + Comp / Video
Zoom -	Vol - / Page -
Focus -	- / Stop
Input 2	Shift + Mode

Original	Sustituto
[> <]/Freeze	Freeze / Timer
Digital Zoom	Blank / Mute
Input 3	Volt / Focus
P.Timer	Shift + Freeze / Timer
Keystone	Shift + Up
Input 4	Mode
Screen	Shift + Source
SEL/Image SEL	Comp / Video
[i]/Info	Help / Info
Filter	Shift + Menu

