



Original	Sustituto
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
AV	AV / Input / RDS
TV	TV/Radio /
I/II	Audio / Lang I/II
OO	Smart / List
Red	Red / Netflix / Search
Green	Green / APP / Repeat






Original	Sustituto
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
P>P	Fav / Marker / PC
PP	Back / Return
[+]	Info / Angle
Mute	Mute / Dimmer
Up	Up
Down	Down
Right	Right
Left	Left
OK	OK
TXT	Text / Goto
Time	Shift + Sleep / Timer
[=i]	Subtitle / EQ
[=+]	Picture / Format
[=x]	Setup / OPT /
[/ =]	Display / Media





Original

Sustituto

	[=?]		Guide / EPG / -/--
	[=◆]		Menu / Home
	[=▲]		CH+ / Page+
	[=▼]		CH- / Page-
	Sleep		Sleep / Timer

Original

Sustituto

