



Original	Sustituto
	Power
	Info / Angle
	Sleep / Timer
	TV/Radio /
	Shift + 7
	Guide / EPG / -/--
	Audio / Lang I/II
	Shift + Red / Netflix /
	Shift + Green / APP /
	Shift + Yellow / YouTube /
	Blue / Prime Video / Random
	Exit / Cancel / Clear
	Menu / Home
	>> / Tune+
<< FAV button"/>	<< / Tune-
	Up
	OK

Original	Sustituto
	Down
	Right
	Vol+
	Vol-
	Left
	Pause / Step / Freeze
	Mute / Dimmer
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0





Original	Sustituto
A	Red / Netflix / Search
B	Green / APP / Repeat
C	Yellow / YouTube / Repeat
F1	Shift + 1
F2	Shift + 2
F3	Shift + 3
F4	Shift + 4
F5	Shift + 5
Nothing Left	Text / Goto
Nothing Right	Picture / Format

Original	Sustituto

