






Original	Sustituto
	M Smart / List
	Power
	1
	2
	3
	4
	5
	6
	7
	8
	9
	Fav / Marker / PC
	0
	Mute / Dimmer
	Info / Angle
	D.Menu / Top
	Subtitle / EQ

Original	Sustituto
	Menu / Home
	Up
	Left
	OK
	Right
	Down
	Vol-
	Vol+
	Play / Slow
	Stop / Hold
	I<< / Preset-
	>>I / Preset+
	Green / APP / Repeat
	CH+ / Page+
	CH- / Page-
	Display / Media

