












Original	Sustituto
 Input	 AV / Input / RDS
 Power	 Power
 Freeze	 Pause / Step / Freeze
 APA	 Smart / List
 Pic Muting	 Mute / Dimmer
 Up	 Up
 Reset	 Exit / Cancel / Clear
 Left	 Left
 Enter	 OK
 Right	 Right
 Down	 Down
 Menu	 Menu / Home
 Wide Mode	 Red / Netflix / Search
 RCP	 Green / APP / Repeat
 Adj. Pic	 Yellow / YouTube / Repeat
 Pic. Mode	 4
 Pic. Mode	 5

Original	Sustituto
 Pic. Mode Cinema	 6
 User 1	 1
 User 2	 2
 User 3	 3
 Bright+	 Vol+
 Contrast+	 >>  / Preset+
 Bright-	 Vol-
 Contrast-	  << / Preset-



Standard