



Original	Sustituto
	Mute / Dimmer
	Guide / EPG / -/--
	Info / Angle
	AV / Input / RDS
	Pause / Step / Freeze
	1
	2
	3
	Fav / Marker / PC
	4
	5
	6
	TV/Radio /
	7
	8
	9
	Back / Return

Original	Sustituto
	CH+ / Page+
	Up
	0
	Audio / Lang I/II
	Vol-
	Left
	OK
	Vol+
	Right
	Text / Goto
	Menu / Home
	CH- / Page-
	Down
	Exit / Cancel / Clear
	Subtitle / EQ
	Red / Netflix / Search
	Smart / List



