



Original	Sustituto	Original	Sustituto
Power	Power		
Open/Close	Eject / Surround		
Skip +10 Folder	0		
Play	Play / Slow		
Pause	Pause / Step / Freeze		
Stop	Stop / Hold		
>>I slider"/> >>I	>>I / Preset+		
I<<	I<< / Preset-		
Vol+	Vol+		
Vol-	Vol-		

