



|          | Original | Sustituto               | Original | Sustituto                 |
|----------|----------|-------------------------|----------|---------------------------|
| 1        | 1        | 1                       | A-B      | Yellow / YouTube / Repeat |
| 2        | 2        | 2                       | Angle    | Info / Angle              |
| 3        | 3        | 3                       | Repeat   | Green / APP / Repeat      |
| 4        | 4        | 4                       | Return   | Back / Return             |
| 5        | 5        | 5                       | OSD      | Display / Media           |
| 6        | 6        | 6                       | I<<      | Shift + I<< / Preset-     |
| 7        | 7        | 7                       | I<<      | I<< / Preset-             |
| 8        | 8        | 8                       | >>I      | Shift + >>I / Preset+     |
| 9        | 9        | 9                       | >>I      | >>I / Preset+             |
| 0        | 0        | 0                       | <<       | << / Tune-                |
| ZOOM     | Zoom     | Zoom / Size             | <<       | Shift + << /              |
| MODE     | Mode     | Shift + Display / Media | >>       | Shift + >> /              |
| TITLE    | Title    | Sound / Title           | >>       | >> / Tune+                |
| AUDIO    | Audio    | Audio / Lang I/II       | Enter    | OK                        |
| SUBTITLE | Subtitle | Subtitle / EQ           | Play     | Play / Slow               |
| MENU     | Menu     | Menu / Home             | Pause    | Pause / Step / Freeze     |
| SETUP    | Setup    | Setup / OPT /           | Stop     | Stop / Hold               |



