



Original	Sustituto
Power	Power
Energy Saving	Sleep / Timer
AV Mode	Picture / Format
Input	AV / Input / RDS
Tv/Rad	TV/Radio /
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
List	Smart / List
0	0
Q.Vlew	Setup / OPT /

Original	Sustituto
Vol+	Vol+
FAV/Mark/Char/Nu	Fav / Marker / PC
P+	CH+ / Page+
Vol-	Vol-
3D	Zoom / Size
Mute/Delete	Mute / Dimmer
P-	CH- / Page-
Menu	Menu / Home
NetCast	Sound / Title
Q.Menu	D.Menu / Top
Up	Up
Left	Left
OK	OK
Right	Right
Down	Down
Exit	Exit / Cancel / Clear
Back	Back / Return



