













































Original		Sustituto		Original		Sustituto	
	Standby		Power		Down		Down
	EQ		Subtitle / EQ		3D		3
	Mute		Mute / Dimmer		Vol-		Vol-
	Clock		Setup / OPT /		Vol+		Vol+
	Alarm		Menu / Home				
	Sleep		Sleep / Timer				
	Mem		Smart / List				
	Up		Up				
	Repeat		Green / APP / Repeat				
	I<<		I<< / Preset-				
	I<<		Left				
	Play / Pause		Play / Slow				
	Play / Pause		Pause / Step / Freeze				
	Play / Pause		OK				
	>>I		>>I / Preset+				
	>>I		Right				
	Source		AV / Input / RDS				

