














Original	Sustituto	Original	Sustituto
 Muting	 Mute / Dimmer	 Volume+	 Vol+
 Power	 Power	 Menu	 Menu / Home
 Timer	 Shift + Sleep / Timer	 Up	 Up
 Clock Call	 Setup / OPT /	 Preset Memory	 Smart / List
 Sleep	 Sleep / Timer	 Treble	 Sound / Title
 TUNER	 6	 Left	 Left
 CD	 3	 Enter	 OK
 iPod	 1	 Right	 Right
 Line	 2	 Bass	 Audio / Lang I/II
 Bluetooth	 9	 Mode	 Info / Angle
 Stop	 Stop / Hold	 Down	 Down
 Play / Pause	 Play / Slow	 Clear	 Exit / Cancel / Clear
 << / Tuning-	 << / Tune-	 S.Bass	 Subtitle / EQ
 I<< / Preset-	 I<< / Preset-	 Dimmer	 Shift + Mute / Dimmer
 >>I / Preset+	 >>I / Preset+	 Shuffle	 Blue / Prime Video / Random
 >> / Tuning+	 >> / Tune+	 Repeat	 Green / APP / Repeat
 Volume-	 Vol-	 Playlist+	 CH+ / Page+



