



Original	Sustituto
VTR	Power
Clock/Counter	Fav / Marker / PC
Timer Rec	Display / Media
+/-	Back / Return
Time Search	Sleep / Timer
Memory/Search	Smart / List
1	1
2	2
3	3
Reset	Exit / Cancel / Clear
4	4
5	5
6	6
Check/Prog	TV/Radio /
7	7
8	8
9	9

Original	Sustituto
Next	>>  / Preset+
VPS	Zoom / Size
10/0	0
-/--	Guide / EPG / -/--
Rec	Rec / Rec Mode
Pause/Still	Pause / Step / Freeze
Stop	Stop / Hold
II>/Still ADV	Blue / Prime Video / Random
<</REW	<< / Tune-
Play	Play / Slow
>>/FF	>> / Tune+
Slow-	Left
Slow	OK
Slow+	Right

