



Original	Sustituto
Standby	Power
Open/Close	Eject / Surround
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Menu	Menu / Home
0	0
Set/Vol	Smart / List
<<	<< / Tune-
Up	Up
>>	>> / Tune+

Original	Sustituto
Left	Left
OK	OK
Right	Right
I<<	I<< / Preset-
Down	Down
>>I	>>I / Preset+
Display	Display / Media
Angle	Info / Angle
Title	Sound / Title
Subtitle	Subtitle / EQ
Mute	Mute / Dimmer
Play	Play / Slow
Pause	Pause / Step / Freeze
Stop	Stop / Hold
Return	Back / Return
Language/Audio	Audio / Lang I/II
Repeat	Green / APP / Repeat



