







































































Original	Sustituto
	 Power
	 Sources
	 Text
	 T.Opt
	 AD
	 *
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 Guide
	 0

Original	Sustituto
	 ...
	 Vol+
	 Mute
	 CH+
	 Vol-
	 Search
	 CH-
	 TV
	 Netflix
	 Home
	 Prime video
	 Disney+
	 Up
	 Rakuten Tv
	 Left
	 OK
	 Right





Original	Sustituto
	Back / Return
	Down
	Zoom / Size
	Smart / List
	Rec / Rec Mode
	Stop / Hold
	<< / Tune-
	Play / Slow
	Pause / Step / Freeze
	>> / Tune+
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random

Original	Sustituto

