



Original	Sustituto
Pause	Pause / Step / Freeze
Power	Power
Mute	Mute / Dimmer
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
FAV	Fav / Marker / PC
0	0
Recall	Back / Return
Digest	Display / Media
Tv Mode	Smart / List

Original	Sustituto
Info	Info / Angle
Menu	Menu / Home
EPG	Guide / EPG / -/-
Exit	Exit / Cancel / Clear
Left	Left
Vol-	Vol-
CH+	CH+ / Page+
Up	Up
Right	Right
Vol+	Vol+
OK	OK
Down	Down
CH-	CH- / Page-
Red	Red / Netflix / Search
Language	Shift + Audio / Lang I/II
Green	Green / APP / Repeat
Audio	Audio / Lang I/II





Original	Sustituto	Original	Sustituto
PAUSE	Yellow / YouTube / Repeat		
TV/RADIO	TV/Radio /		
TELETEXT	Blue / Prime Video / Random		
TELETEXT	Text / Goto		
SUBTITLE	Subtitle / EQ		

Original	Sustituto

