



























































| Original | Sustituto | Original | Sustituto |
|--|---|---|--|
|  Power |  Power |  1 |  1 |
|  Rec |  Rec / Rec Mode |  2 |  2 |
|  TV |  TV/Radio / |  3 |  3 |
|  TXT |  Text / Goto |  4 |  4 |
|  Home |  Menu / Home |  5 |  5 |
|  Up |  Up |  6 |  6 |
|  i |  Info / Angle |  7 |  7 |
|  Left |  Left |  8 |  8 |
|  OK |  OK |  9 |  9 |
|  Right |  Right |  EPG |  Guide / EPG / -/-- |
|  Down |  Down |  0 |  0 |
|  Back |  Back / Return | | |
|  Vol+ |  Vol+ | | |
|  P+ |  CH+ / Page+ | | |
|  Vol- |  Vol- | | |
|  W |  Display / Media | | |
|  P- |  CH- / Page- | | |

