



Original	Sustituto
	Input / RDS
	Power
	Sound / Title
	Zoom / Size
	Picture / Format
	TV/Radio /
	Display / Media
	Exit / Cancel / Clear
	Vol+
	Vol-
	Info / Angle
	Mute / Dimmer
	Red / Netflix / Search
	Audio / Lang I/II
	Up
	OK
	Down

Original	Sustituto
	Play / Slow
	Pause / Step / Freeze
	I<< / Preset-
	>>I / Preset+

