









































































Original	Sustituto	Original	Sustituto
 Power	 Power	 Left / Vol-	 Vol-
 1	 1	 Left / Vol-	 Left
 2	 2	 Down / P-	 Down
 3	 3	 Down / P-	 CH- / Page-
 4	 4	 i	 Info / Angle
 5	 5	 AKT / TV-Guide	 Guide / EPG / -/-
 6	 6	 Mute	 Mute / Dimmer
 7	 7	 TXT	 Text / Goto
 8	 8	 Red / Picture	 Picture / Format
 9	 9	 Red / Picture	 Red / Netflix / Search
 0 / AV	 AV / Input / RDS	 Green / Timer	 Sleep / Timer
 0 / AV	 0	 Green / Timer	 Green / APP / Repeat
 Up / P+	 CH+ / Page+	 Yellow / Pause	 Yellow / YouTube / Repeat
 Up / P+	 Up	 Yellow / Pause	 Pause / Step / Freeze
 OK	 OK	 Blue / Audio	 Blue / Prime Video / Random
 Right / Vol+	 Right	 Blue / Audio	 Audio / Lang I/II
 Right / Vol+	 Vol+	 Color-	 I<< / Preset-





Original	Sustituto
 Color+	 >>I / Preset+
 Brightness-	 << / Tune-
 Brightness+	 >> / Tune+
 PIP	 D.Menu / Top
 ?	 Menu / Home
 Size	 Zoom / Size
 AUX	 Shift + 7
 AUX	 Smart / List

Original	Sustituto

