



Original	Sustituto
 Power	 Power
 CBL/SAT	 0
 Media Player	 Guide / EPG / -/--
 Blu-ray/DVD	 2
 Game	 Fav / Marker / PC
 AUX	 7
 Tuner	 6
 Phono	 5
 TV Audio	 1
 CD	 3
 USB	 8
 Bluetooth	 9
 Internet Radio	 4
 Heos	 Smart / List
 CH+	 CH+ / Page+
 ECO	 Zoom / Size
 Volume+	 Vol+

Original	Sustituto
 CH-	 CH- / Page-
 Mute	 Mute / Dimmer
 Volume-	 Vol-
 Info	 Info / Angle
 Option	 Menu / Home
 Up	 Up
 Left	 Left
 Enter	 OK
 Right	 Right
 Back	 Back / Return
 Down	 Down
 Setup	 Setup / OPT /
 I<</Tune-	 I<< / Preset-
 I<</Tune-	 << / Tune-
 Play/Pause	 Play / Slow
 >>I/Tune+	 >>I / Preset+
 >>I/Tune+	 >> / Tune+





Original	Sustituto
Power	Power
CBL/SAT	0
Media Player	Guide / EPG / -/--
Blu-ray/DVD	2
Game	Fav / Marker / PC
AUX	7
Tuner	6
Phono	5
TV Audio	1
CD	3
USB	8
Bluetooth	9
Internet Radio	4
Heos	Smart / List
CH+	CH+ / Page+
Volume+	Vol+
CH-	CH- / Page-

Original	Sustituto
Mute	Mute / Dimmer
Volume-	Vol-
Up	Up
Left	Left
Enter	OK
Right	Right
Back	Back / Return
Down	Down
I<</Tune-	I<< / Preset-
I<</Tune-	<< / Tune-
Play/Pause	Play / Slow
>>I/Tune+	>>I / Preset+
>>I/Tune+	>> / Tune+
Band	Display / Media
Stop/Mode	Stop / Hold
Memory	Eject / Surround
Smart Select 1	Red / Netflix / Search



