



Original	Sustituto
Display	Display / Media
Power	Power
Normal	Shift + Display / Media
Tv/Av/DVD	TV/Radio /
Sleep	Sleep / Timer
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Aspect	Smart / List
0	0
Sound Mode	Sound / Title

Original	Sustituto
Vol-	Vol-
Tv Menu	Menu / Home
Vol+	Vol+
Up	Up
PR+	CH+ / Page+
Left	Left
Right	Right
Mute	Mute / Dimmer
PR-	CH- / Page-
Down	Down
OK/Enter	OK
DVD Menu	D.Menu / Top
o))	AV / Input / RDS
I<<	I<< / Preset-
>>I	>>I / Preset+
[...]	Subtitle / EQ
<<	<< / Tune-



