



Original	Sustituto	Original	Sustituto
Power	Power	0/VCR	0
[ + ]	Info / Angle	-/--	Guide / EPG / -/--
Mute	Mute / Dimmer	Vol-	Vol-
Tv/AV	AV / Input / RDS	Tv/Text	Text / Goto
1	1	F.P.	Sleep / Timer
2	2	[i]/Index	TV/Radio /
3	3	[ + ]/Hold	Picture / Format
CH+	CH+ / Page+	Red	Red / Netflix / Search
4	4	Green	Green / APP / Repeat
5	5	Yellow	Yellow / YouTube / Repeat
6	6	Blue	Blue / Prime Video / Random
CH-	CH- / Page-	<<	<< / Tune-
7	7	Play	Play / Slow
8	8	>>	>> / Tune+
9	9	Stop	Stop / Hold
Vol+	Vol+	[?]/Reveal	Smart / List
C	Back / Return	[o]/Time Text	Display / Media



