



Original	Sustituto
	Power
	Ambilight
	Butterfly
	Smart
	Pair / Sources
	Up
	Left
	OK
	Right
	Down
	Back
	Home
	List / TV Guide
	<<
	Play
	>>
	Stop
	Power
	Picture / Format
	Display / Media
	Smart / List
	AV / Input / RDS
	Up
	Left
	OK
	Right
	Down
	Back / Return
	Shift + Menu /
	Guide / EPG / -/--
	<< / Tune-
	Play / Slow
	>> / Tune+
	Stop / Hold

Original	Sustituto
	Pause
	Rec
	Red
	Green
	Yellow
	Blue
	Vol+
	Netflix
	CH+
	Mute
	FPlay
	TV Exit
	Vol-
	Rakuten TV
	CH-
	1
	2
	Pause / Step / Freeze
	Rec / Rec Mode
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	Vol+
	Shift + Red / Netflix /
	CH+ / Page+
	Mute / Dimmer
	Shift + Green / APP /
	Exit / Cancel / Clear
	Vol-
	Shift + Yellow / YouTube /
	CH- / Page-
	1
	2



