





































| Original | Sustituto |
|--|--|
|  POWER |  Power |
|  MUTE |  Mute |
|  P.MODE |  +  Shift + Format |
|  S.MODE |  Dual |
|  SLEEP |  Sleep |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  -/- |  Guide |
|  EXIT |  Exit |

| Original | Sustituto |
|--|--|
|  INPUT |  AV |
|  MENU |  Menu |
|  RECALL |  Pre Ch |
|  |  Left |
|  |  Right |
|  |  Up |
|  |  Down |
|  ENTER |  Ok |
|  VOL+ |  Vol + |
|  VOL- |  Vol - |
|  CH+ |  Ch + |
|  CH- |  Ch - |
|  RED/DVD |  Red |
|  GREEN/DVD |  Green |
|  YELLOW/TITLE |  Yellow |
|  BLUE/LANG |  Blue |
|  DISPLAY |  Info |



