

















































































Original	Sustituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Last CH/Delete	 Pre Ch
 -/-	 Guide
 AV	 AV
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute

Original	Sustituto
 CH+	 Ch +
 CH-	 Ch -
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 TV	 TV/R
 Play	 Play
 Text	 Text
 Pause	 Pause
 Hold	 Options
 >>	 >>
 Mix	 Sleep


























Original	Sustituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Last CH/Delecte	 Pre Ch
 -/--	 Guide
 AV	 AV
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute

Original	Sustituto
 CH+	 Ch +
 CH-	 Ch -
 Menu	 Menu
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 <<	 <<
 >>	 >>
 Play	 Play
 Stop	 Stop
 TV	 TV/R





	Original	Sustituto		Sustituto
	Text	 Text		
	Pause	 Pause		
	Hold	 Options		
	Mix	 Sleep		
	Record	 Rec		
	Pg Up	 Shift + Up		
	Pg Down	 Shift + Down		
	Refresh	 Back		
	Pg Back	 Shift + Left		
	Pg Fwd	 Shift + Right		
	Home	 Smart		

Original	Sustituto

