



Original	Sustituto
	Eject / Surround
	Mute / Dimmer
	Shift + 2
	Shift + 6
	Yellow / YouTube / Repeat
	Shift + 7
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	Shift + Guide / EPG / -/-

Original	Sustituto
	Setup / OPT /
	Guide / EPG / -/-
	Fav / Marker / PC
	Rec / Rec Mode
	D.Menu / Top
	Up
	Down
	Left
	Right
	OK
	Pause / Step / Freeze
	Play / Slow
	Stop / Hold
	Vol-
	Vol+
	CH- / Page-
	CH+ / Page+





Original	Sustituto
I<<	I<< / Preset-
>>I	>>I / Preset+
<<	<< / Tune-
>>	>> / Tune+
Zoom	Zoom / Size
Prog	TV/Radio /
Slow	Shift + Play /
A-B	Shift + YouTube / YouTube /
Goto	Text / Goto
Title	Sound / Title
Menu	Menu / Home
Display	Display / Media
Subtitle	Subtitle / EQ
N/P	Shift + Setup / OPT / Tools
Language	Audio / Lang I/II
Angle	Info / Angle
Resume	Shift + Display / Media

Original	Sustituto
Repeat	Green / APP / Repeat
R/L	Shift + Subtitle / EQ
Video	Shift + 4
Return	Back / Return

