







































































Original		Sustituto		Original		Sustituto	
	Power		Power		4		4
	OK		Ok		5		5
	Up		Up		6		6
	Down		Down		7		7
	Right		Right		8		8
	Left		Left		9		9
	Menu		Menu		0		0
	Mute		Mute		P<P		Pre Ch
	> <		Smart		[i+]		Info
	[≡]		Text		[112]		Options
	P+		Ch +		[-O-]/Active Control		Media
	P-		Ch -		[<>]		Format
	Vol+		Vol +		Source		AV
	Vol-		Vol -		(O		TV/R
	1		1		Red		Red
	2		2		Green/Timer		Green
	3		3		Yellow/[]		Yellow









































































Original	Sustituto	Original	Sustituto
Blue/[...]	Blue	P- AMP	Shift + Ch -
Rec	Rec	Mute AMP	Shift + Mute
<<	<<	Vol+ AMP	Shift + Vol +
Stop	Stop	Vol- AMP	Shift + Vol -
Play	Play	1 AMP	Shift + 1
>>	>>	2 AMP	Shift + 2
[[]]	Guide	3 AMP	Shift + 3
Power AMP	Shift + Power	4 AMP	Shift + 4
[] AMP	Shift + Text	5 AMP	Shift + 5
[[]] AMP	Shift + Guide	6 AMP	Shift + 6
OK AMP	Shift + Ok	7 AMP	Shift + 7
Up AMP	Shift + Up	8 AMP	Shift + 8
Down AMP	Shift + Down	9 AMP	Shift + 9
Right AMP	Shift + Right	0 AMP	Shift + 0
Left AMP	Shift + Left	P<P AMP	Shift + Pre Ch
Menu AMP	Shift + Menu	>> AMP	Shift + >>
P+ AMP	Shift + Ch +	<< AMP	Shift + <<









































































Original	Sustituto	Original	Sustituto
	Power		Power
	Source		AV
	>>		>>
	<<		<<
	Stop		Stop
	Play		Play
	[[I]]		Guide
	[≡]		Text
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	> <		Smart
	Menu		Menu
	Mute		Mute
	P+		Ch +
	P-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	[i+]		Info
	P<P		Pre Ch
	[1]2		Options
	[-O]/Active Control		Media
























Original	Sustituto	Original	Sustituto
	Power		Power
	Source		AV
	(O		TV/R
	Red		Red
	Green/Timer		Green
	Yellow/[]		Yellow
	Blue/[...]		Blue
	>>		>>
	Rec		Rec
	<<		<<
	Stop		Stop
	Play		Play
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Mute		Mute
	P+		Ch +
	P-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	> <		Smart
	Menu		Menu
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0





























































Original	Sustituto	Original	Sustituto
	[i+]		Info
	P<P		Pre Ch
	[1 2]		Options
	[-O-]/Active Control		Media
	[<>]		Format
	Power VCR		Shift + Power
	Source VCR		Shift + AV
	Rec VCR		3D
	>> VCR		Shift + >>>
	<< VCR		Shift + <<<
	Stop VCR		Shift + Stop
	Play VCR		Shift + Play
	OK VCR		Shift + Ok
	Up VCR		Shift + Up
	Down VCR		Shift + Down
	Right VCR		Shift + Right
	Left VCR		Shift + Left
	> < VCR		Shift + Smart
	Menu VCR		Shift + Menu
	P+ VCR		Shift + Ch +
	P- VCR		Shift + Ch -
	1 VCR		Shift + 1
	2 VCR		Shift + 2
	3 VCR		Shift + 3
	4 VCR		Shift + 4
	5 VCR		Shift + 5
	6 VCR		Shift + 6
	7 VCR		Shift + 7
	8 VCR		Shift + 8
	9 VCR		Shift + 9
	0 VCR		Shift + 0
	[i+] VCR		Shift + Info
	P<P VCR		Shift + Pre Ch





Original	Sustituto	Original	Sustituto
	Power		Power
	>>		>>
	<<		<<
	Stop		Stop
	Play		Play
	[[I]]		Guide
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	> <		Smart
	Mute		Mute
	Vol+		Vol +
	Vol-		Vol -
	P+		Ch +
	P-		Ch -
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	[i+]		Info
	P<P		Pre Ch

