




































































Original	Sustituto
 Power	 Power
 Eject	 Eject / Surround
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 OSD / Info	 Display / Media
 OSD / Info	 Info / Angle
 4	 4
 5	 5
 6	 6
 V-Mode	 Picture / Format
 7	 7
 8	 8
 9	 9
 P/N / Fav	 Fav / Marker / PC
 0	 0

Original	Sustituto
 10+	 Shift + Guide / EPG / -/-
 Goto	 Shift + Text /
 Setup	 Setup / OPT /
 Angle	 Shift + Info / Angle
 Text / Title	 Sound / Title
 Text / Title	 Text / Goto
 Subtitle	 Subtitle / EQ
 Menu	 Menu / Home
 Up	 Up
 Left	 Left
 Enter	 OK
 Right	 Right
 Down	 Down
 PBC / EPG	 Guide / EPG / -/-
 Source	 AV / Input / RDS
 Exit	 Exit / Cancel / Clear
 <<	 << / Tune-





Original	Sustituto
	<b>SLOW</b> Play / Slow
	<b>STEP - FREEZE</b> Pause / Step / Freeze
	<b>PRESET-</b> I<< / Preset-
	<b>TUNE+</b> >> / Tune+
	<b>HOLD</b> Stop / Hold
	<b>PRESET+</b> >>I / Preset+
	<b>PROGRAM TV/RADIO</b> TV/Radio /
	<b>NETFLIX SEARCH</b> Red / Netflix / Search
	<b>APP REPEAT</b> Green / APP / Repeat
	<b>SHIFT + STEP - FREEZE</b> Shift + Pause / Step /
	<b>YouTube REPEAT A-B</b> Yellow / YouTube / Repeat
	<b>SHIFT + APP REPEAT</b> Shift + Green / APP /
	<b>Prime Video RANDOM</b> Blue / Prime Video / Random
	<b>SHIFT + YouTube REPEAT A-B</b> Shift + Yellow / YouTube /
	<b>SIZE ZOOM</b> Zoom / Size
	<b>SHIFT + SLOW</b> Shift + Play /
	<b>TOP MENU D.MENU</b> D.Menu / Top

Original	Sustituto
<b>AUDIO</b> Audio	<b>LANG I/II AUDIO</b> Audio / Lang I/II
<b>CH-</b> CH-	<b>CH PAGE -</b> CH- / Page-
<b>CH+</b> CH+	<b>CH PAGE +</b> CH+ / Page+
<b>VOL-</b> Vol-	<b>VOL -</b> Vol-
<b>VOL+</b> Vol+	<b>VOL +</b> Vol+

