






















Original	Sustituto
	 Power
	 Subt
	 Text
	 TV/R
	 Info
	 Options
	 Dual
	 Format
	 Exit
	 Smart
	 AV
	 Pre Ch
	 Ch +
	 Ch -
	 Up
	 Down
	 Right

Original	Sustituto
	 Left
	 Vol +
	 Vol -
	 Menu
	 Red
	 Green
	 Yellow
	 Blue
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9





Original	Sustituto
	0
	PP
	Mute

Original	Sustituto

