







































Original	Sustituto	Original	Sustituto
	Power		Power
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	[=+]		Setup / OPT /
	[/=]		AV / Input / RDS
	[=x]		Picture / Format
	[=]		Text / Goto
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0/AV		0
	P+		CH+ / Page+
	P-		CH- / Page-
	Vol+		Vol+
	Vol-		Vol-
	N/E		OK
	Right		Right
	Left		Left
	Up		Up
	Down		Down
	P/C		Back / Return
	i		Info / Angle
	Mute		Mute / Dimmer
	Color-		<< / Tune-
	Color+		>> / Tune+
	Brightness-		I<< / Preset-





Original	Sustituto
 Power	 Power
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 0/AV	 0
 Vol+	 Vol+
 Vol-	 Vol-
 P+	 CH+ / Page+
 P-	 CH- / Page-
 Down	 Down
 Up	 Up
 N/E	 OK
 Right	 Right
 Left	 Left
 i	 Info / Angle
 Mute	 Mute / Dimmer

Original	Sustituto
 Rec	 Rec / Rec Mode
 Stop	 Stop / Hold
 Pause	 Pause / Step / Freeze
 Play	 Play / Slow
 Tint-	 Display / Media
 Tint+	 Smart / List
 << / Tune-	 << / Tune-
 >> / Tune+	 >> / Tune+
 Zoom / Size	 Zoom / Size
 I<< / Preset-	 I<< / Preset-
 >>I / Preset+	 >>I / Preset+

