






































































































Original	Sustituto	Original	Sustituto
PWR On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Epg	 +  Shift + Guide	Exit	 Exit
App	 Media	Menu Down	 Down
Opt?	 Options	Audio	 Dual
TV	 TV/R	Back	 Back
Info	 +  Shift + Info	Volume+	 Vol +
Subt.List	 Subt	CH/Page+	 Ch +
Sleep Timer	 Sleep	Volume-	 Vol -
Video	 D. Menu	CH/Page-	 Ch -
Text	 Text	1. ?	 1
Zoom	 Eject	2abc	 2
TV/SAT	 AV	3def	 3
Menu	 Menu	4ghi	 4
Menu Up	 Up	5jkl	 5
Display	 Info	6mno	 6
Menu Left	 Left	7pqrm	 7




Original	Sustituto	Original	Sustituto
8tuv	 8	+	 Shift + Subt
9wxyz	 9	Auth./DISEQC	 Shift + Smart
Guide Pilote	 Guide	Sys/Serv	 Shift + Sleep
0/10	 0	Home Cinema	 Smart
FAV Pref.	 Pre Ch	Scan/Setup	 Shift + Options
Red	 Red	Interat	 Shift + D. Menu
Green	 Green	Pers.	 Shift + Eject
Yellow	 Yellow	Tune-	 Shift + Left
Freeze	 Stop	East	 >>I
Blue	 Blue	H/V Play	 Play
Dev	 List	LNB F.Forward	 >>
22Khz	 3D	Lang./Rewind	 <<
West	 I<<	Alt/16:9	 Format
Radio	 Shift + TV/R	Aft/Caf	 Shift + Ok
On/Off	 Shift + Power	Tune+	 Shift + Right
Dec/Pause	 Pause		 Shift + Exit
	 Shift + Mute	Browse	 Shift + Back


































































Original	Sustituto	Original	Sustituto
PWR On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Epg	 +  Shift + Guide	Exit	 Exit
Subt.List	 Subt	Menu Down	 Down
Opt?	 Options	Back	 Back
App	 Media	Audio	 Dual
Info	 +  Shift + Info	Volume+	 Vol +
Sleep Timer	 Sleep	CH/Page+	 Ch +
TV	 TV/R	Volume-	 Vol -
Video	 D. Menu	CH/Page-	 Ch -
Text	 Text	1. ?	 1
Zoom	 Eject	2abc	 2
TV/SAT	 AV	3def	 3
Menu	 Menu	4ghi	 4
Menu Up	 Up	5jkl	 5
Display	 Info	6mno	 6
Menu Left	 Left	7pqrm	 7















Original	Sustituto	
8tuv	 8	8
9wxyz	 9	9
Guide Pilote	 GUIDE	Guide
0/10	 0	0
FAV Pref.	 PRE-CH	Pre Ch
Red	 A	Red
Green	 B	Green
Yellow	 C	Yellow
Blue	 D	Blue
On/Off	 + 	Shift + Power
Scan/Setup	 + 	Shift + Options
Radio	 + 	Shift + TV/R
	 + 	Shift + Mute
22Khz	 LIST	List
+	 + 	Shift + Subt
Sys/Serv	 + 	Shift + Sleep
Pers.	 + 	Shift + Eject

Original	Sustituto	
SAT Sky	 + 	Shift + AV
Navi Mode	 + 	Shift + Menu
Browse	 + 	Shift + Media
Search	 + 	Shift + Up
Auth./DISEQC	 3D	3D
Tune-	 + 	Shift + Left
Tune+	 + 	Shift + Right
East	 >>	>>
	 + 	Shift + Exit
Lang./Rewind	 <<	<<
H/V Play	 PLAY MODE	Play
Store	 + 	Shift + Down
Alt/16:9	 PICTURE FORMAT	Format
	 + 	Shift + Vol +
Home Cinema	 HOME SMART	Smart
	 + 	Shift + Vol -







































Original	Sustituto	Original	Sustituto
PWR On/Off	 Power	Exit	 Exit
Mute	 Mute	Menu Down	 Down
Opt?	 Options	Back	 Back
Info	 +  Shift + Info	Volume+	 Vol +
Subt.List	 Subt	CH/Page+	 Ch +
Sleep Timer	 Sleep	Audio	 Dual
TV	 TV/R	Volume-	 Vol -
Video	 D. Menu	CH/Page-	 Ch -
Text	 Text	1. ?	 1
Zoom	 Eject	2abc	 2
TV/SAT	 AV	3def	 3
Menu	 Menu	4ghi	 4
Menu Up	 Up	5jkl	 5
Display	 Info	6mno	 6
Menu Left	 Left	7pqrm	 7
OK Enter	 Ok	8tuv	 8
Menu Right	 Right	9wxyz	 9



Original	Sustituto	Original	Sustituto
Guide Pilote	 Guide		
0/10	 0		
FAV Pref.	 Pre Ch		
Red	 Red		
Green	 Green		
Dec/Pause	 Pause		
Lang./Rewind	 <<		
Freeze	 Stop		
LNB F.Forward	 >>		
H/V Play	 Play		
East	 >>		
Yellow	 Yellow		
Blue	 Blue		




Original	Sustituto	Original	Sustituto
PWR On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Epg	 +  Shift + Guide	Exit	 Exit
Subt.List	 Subt	Menu Down	 Down
Opt?	 Options	Back	 Back
App	 Media	Audio	 Dual
Info	 +  Shift + Info	Volume+	 Vol +
Sleep Timer	 Sleep	CH/Page+	 Ch +
TV	 TV/R	Volume-	 Vol -
Video	 D. Menu	CH/Page-	 Ch -
Text	 Text	1. ?	 1
Zoom	 Eject	2abc	 2
TV/SAT	 AV	3def	 3
Menu	 Menu	4ghi	 4
Menu Up	 Up	5jkl	 5
Display	 Info	6mno	 6
Menu Left	 Left	7pqrm	 7





Original	Sustituto	
8tuv	 8	8
9wxyz	 9	9
Guide Pilote	 GUIDE	Guide
0/10	 0	0
FAV Pref.	 PRE-CH	Pre Ch
Red	 A	Red
Green	 B	Green
Yellow	 C	Yellow
Blue	 D	Blue
On/Off	 + 	Shift + Power
Scan/Setup	 + 	Shift + Options
	 + 	Shift + Mute
Dec/Pause	 II	Pause
+	 + 	Shift + Subt
Sys/Serv	 + 	Shift + Sleep
Interat	 + 	Shift + D. Menu
SAT Sky	 + 	Shift + AV

Original	Sustituto	
22Khz	 LIST	List
Radio	 + 	Shift + TV/R
Navi Mode	 + 	Shift + Menu
Search	 + 	Shift + Up
Tune-	 + 	Shift + Left
Tune+	 + 	Shift + Right
	 + 	Shift + Exit
Store	 + 	Shift + Down
	 + 	Shift + Vol +
	 + 	Shift + Ch +
	 + 	Shift + Vol -
Home Cinema	 SMART	Smart
	 + 	Shift + Ch -
De-emph	 + 	Shift + 1
Swap	 + 	Shift + 2
P.lock	 + 	Shift + 3
Wn	 + 	Shift + 4



