



Original	Sustituto	Original	Sustituto
 Power	 Power	 ZAP	 Pre Ch
 Source	 AV	 Format	 Format
 TV	 TV/R	 Mute	 Mute
 VIDEO	 Smart	 PIP	 3D
 PC	 Media	 Text	 Text
 1	 1	 Up / P+	 Up
 2	 2	 Up / P+	 Ch +
 3	 3	 Down / P-	 Down
 4	 4	 Down / P-	 Ch -
 5	 5	 Right / Vol+	 Right
 6	 6	 Right / Vol+	 Vol +
 7	 7	 Left / Vol-	 Left
 8	 8	 Left / Vol-	 Vol -
 9	 9	 Menu	 Menu
 0	 0	 PIP Swap	 Back
 i	 Info	 Auto	 Options
 List	 List	 Sound	 Dual



