















Original	Sustituto
 Power	 Power
 TDT / A	 Smart
 16:9 / B	 Format
 SAT / C	 Media
 AUX / D	 AV
 INF / E	 Info
 Sleep / F	 Sleep
 TV/RA	 TV/R
 EPG	 Guide
 Red / Text	 Red
 Red / Text	 Text
 Green / Back	 Green
 Green / Back	 Back
 Yellow / Subtitle	 Yellow
 Yellow / Subtitle	 Subt
 Blue / Audio	 Blue
 L/R	 List

Original	Sustituto
 Blue / Audio	 Dual
 Up	 Up
 Left / Vol-	 Left
 Left / Vol-	 Vol -
 OK	 Ok
 Right / Vol+	 Right
 Right / Vol+	 Vol +
 Down	 Down
 Exit	 Exit
 Menu	 Menu
 <<	 <<
 <<	 Ch -
 >>	 >>
 >>	 Ch +
 1	 1
 2	 2
 3	 3





Original	Sustituto
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Pause	Pause
Mute	MUTE Mute
F1	SHIFT + 1 Shift + 1
F2	SHIFT + 2 Shift + 2
F3	SHIFT + 3 Shift + 3
F4	SHIFT + 4 Shift + 4
F5	SHIFT + 5 Shift + 5

Original	Sustituto

