





































Original	Sustituto	Original	Sustituto
	Power		Power
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Sleep		Sleep / Timer
	0		0
	Recall		Back / Return
	Vol+		Vol+
	I/II		Audio / Lang I/II
	PR+		CH+ / Page+

Original	Sustituto	Original	Sustituto
	Vol-		Vol-
	Input		AV / Input / RDS
	PR-		CH- / Page-
	Up		Up
	Left		Left
	Enter		OK
	Right		Right
	Menu		Menu / Home
	Down		Down
	Exit		Exit / Cancel / Clear
	Favourite		Fav / Marker / PC
	FAV-		Shift + CH- /
	FAV+		Shift + CH+ /
	Info		Info / Angle
	P-Mode		Picture / Format
	S-Mode		Sound / Title
	ARC		Display / Media







































	Original	Sustituto	
	EPG	Guide / EPG / -/--	
	Text	Text / Goto	
	Mix	+ Shift + Text /	
	Size	Zoom / Size	
	Reveal	D.Menu / Top	
	Hold	Stop / Hold	
	Index	Smart / List	
	S.Page	Eject / Surround	
	S.TITL	Subtitle / EQ	
	Red	Red / Netflix / Search	
	Green	Green / APP / Repeat	
	Yellow	Yellow / YouTube / Repeat	
	Blue	Blue / Prime Video / Random	

Original	Sustituto





Original	Sustituto
Update	 Shift + D.Menu / Top Menu
Aft/Caf	 Shift + AV / Input / RDS
Reveal	 Setup / OPT /
Off/Tim	 Eject / Surround
Game Coo	 Smart / List
2.Fav P/C 2.	 Fav / Marker / PC
Chan.Down	 CH- / Page-
1	 1
2	 2
3	 3
4	 4
5	 5
6	 6
7	 7
8	 8
9	 9
Guide -/-- 1.	 Guide / EPG / -/--

Original	Sustituto
0/10	 0
Menu audio	 Audio / Lang I/II
Red	 Red / Netflix / Search
Green	 Green / APP / Repeat
Yellow	 Yellow / YouTube / Repeat
Blue	 Blue / Prime Video / Random
Color+ P.Std	 Picture / Format
Color- S.Std	 Sound / Title
Audio+	 Shift + Vol+
Tune-	 << / Tune-
Tune+	 >> / Tune+
Menu	 Menu / Home
Mute	 Mute / Dimmer
Info	 Info / Angle
Subt.List	 Subtitle / EQ
Txt Stop	 Stop / Hold
Sleep Timer	 Sleep / Timer



