















































































| Original | Sustituto |
|---|---|
|  Power |  Power |
|  Mute |  Mute |
|  Eject |  Eject |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  Recall |  Pre Ch |
|  Shift + Guide |  Shift + Guide |
|  Vol+ |  Vol + |
|  Aspect |  Format |

| Original | Sustituto |
|---|--|
|  Nicam |  Shift + Dual |
|  Vol- |  Vol - |
|  CH+ |  Ch + |
|  CH- |  Ch - |
|  Enter |  Ok |
|  Up |  Up |
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |
|  Display |  Shift + Info |
|  LCD Menu |  Menu |
|  Exit/DVD Setup |  Exit |
|  Sleep |  Sleep |
|  Input |  AV |
|  Red/Prog |  Red |
|  Tv/Radio |  TV/R |
|  Green/Intro/Audio |  Green |





| | Original | Sustituto | | Sustituto |
|---|----------------------|---|----------------|-----------|
|  | Yellow/Repeat/Freeze |  | Yellow | |
|  | Blue/A-B |  | Blue | |
|  | EPG |  | Guide | |
|  | Text |  | Text | |
|  | Subtitle |  | Subt | |
|  | D.Menu |  | D. Menu | |
|  | Title |  | Options | |
|  | Zoom/Subpage |  | Shift + Eject | |
|  | D.Disp |  | Info | |
|  | Goto |  | Shift + Pre Ch | |
|  | P.Mode |  | Shift + Format | |
|  | >>I/Hold |  | Shift + Ch - | |
|  | Play/Fav |  | Play | |
|  | Stop/FAV- |  | Stop | |
|  | >I/FAV+ |  | >>I | |
|  | I<< |  | I<< | |
|  | Audio/Lang |  | Shift + Menu | |

| | Original | Sustituto | | Sustituto |
|---|--------------|---|------|-----------|
|  | <</Index |  | << | |
|  | >>/Size |  | >> | |
|  | Angle/Reveal |  | Rec | |
|  | S.Mode |  | Dual | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

