


























































































Original	Sustituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--	 SHIFT +  GUIDE Shift + Guide
 Nicam	 OPT Options
 Source	 AV AV
 S.Mode	 SHIFT +  DUAL Shift + Dual
 Sleep	 SLEEP Sleep

Original	Sustituto
 P.Mode	 SHIFT +  PICTURE Shift + Format
 Recall	 BACK Back
 Menu	 MENU Menu
 Display	 INFO Info
 Media	 MEDIA Media
 Exit	 EXIT Exit
 Rec	 REC MODE Rec
 CH -	 CH -
 Vol +	 VOL + Vol +
 Vol -	 VOL - Vol -
 Guide	 GUIDE Guide
 CH +	 CH +
 Fav +	 PRE-CH Pre Ch
 Up	 Up
 TV / Radio	 TV/R TV/R
 Fav -	 SHIFT +  PRE-CH Shift + Pre Ch
 Down	 Down





Original	Sustituto
 Right	 Right
 Left	 Left
 Enter	 Ok
 Play/Pause / Hold	 Play
 Play/Pause / Hold	 Pause
 Aspect	 Format
 << / Size	 <<
 >> / Reveal	 >>
 Stop / Index	 Stop
 Lang	 Dual
 I<< / Subpage	 I<<
 >>I / Auto	 >>I
 Subtitle	 Subt
 Text	 Text
 Red	 Red
 Green	 Green
 Yellow	 Yellow

Original	Sustituto
 Cyan	 Blue

