


































Original	Sustituto
 Standby	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 SAT List	 Smart
 TV/R	 TV/R
 Menu	 Menu
 Info	 Info
 Back	 Back

Original	Sustituto
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 CH/PG+	 Ch +
 CH/PG-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 TV/STB	 Media
 EPG	 Guide
 FAV	 Pre Ch
 Red/Audio	 Red
 Green/Subt	 Green
 Yellow/Text	 Yellow
 Blue/Sleep	 Blue



