





Original	Sustituto
	Mute / Dimmer
	Power
	Back / Return
	Audio / Lang I/II
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	Fav / Marker / PC
	Display / Media
	Menu / Home

Original	Sustituto
	Info / Angle
	Left
	Up
	CH+ / Page+
	Right
	Down
	CH- / Page-
	Vol-
	Vol+
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	TV/Radio /
	AV / Input / RDS
	Text / Goto
	Shift + Goto Text / Goto





Original		Sustituto		Original		Sustituto	
	Subcode		Sleep / Timer				
	Hold		Stop / Hold				
	Cancel		Exit / Cancel / Clear				
	Size		Zoom / Size				
	Reveal		Picture / Format				
	Index		OK				

