































































Original	Sustituto
	 Power
	 Mute / Dimmer
	 1
	 2
	 3
	 Eject / Surround
	 4
	 5
	 6
	 Shift + Text /
	 7
	 8
	 9
	 0
	 Menu / Home
	 AV / Input / RDS
	 Up

Original	Sustituto
	 Left
	 OK
	 Right
	 Down
	 D.Menu / Top
	 Exit / Cancel / Clear
	 Vol+
	 Sound / Title
	 CH- / Page-
	 Vol-
	 Picture / Format
	 CH+ / Page+
	 Sleep / Timer
	 Shift + Picture / Format
	 Setup / OPT /
	 Shift + Back / Return
	 Text / Goto





	Original	Sustituto		Original	Sustituto
		EPG		Guide / EPG / -/--	
		Play		Play / Slow	
		Pause		Pause / Step / Freeze	
		Stop		Stop / Hold	
		FAV		Fav / Marker / PC	
		Info		Info / Angle	
		Red/DVD/USB		Red / Netflix / Search	
		Green/Title		Green / APP / Repeat	
		Yellow/PBC		Yellow / YouTube / Repeat	
		Blue/Angle		Blue / Prime Video / Random	
		<<		<< / Tune-	
		>>		>> / Tune+	
		I<<		I<< / Preset-	
		>>I		>>I / Preset+	
		Return		Back / Return	
		Display		Display / Media	
		DVD Audio		Audio / Lang I/II	
		Subtitle		Subtitle / EQ	
		Reveal		Shift + Exit / Cancel / Clear	
		Hold		Shift + Stop /	
		List		Smart / List	
		Index		TV/Radio /	
		Subpage		Shift + Smart / List	
		Size		Zoom / Size	
		Mix		Shift + Display / Media	
		Freeze		Shift + Pause / Step /	

