



Original	Sustituto	Original	Sustituto
Power	Power	Page Up	>>
Eco	3D	Page Down	<<
Sleep	Sleep	Green/Movie	Green
CBL/SAT	1	Red/Music	Red
DVD/Blu-ray	2	Blue/Game	Blue
Blu-ray	3	Yellow/Pure	Yellow
Game	4	Info	Info
AUX	5	Option	Options
Media Player	6	Back	Back
iPod/USB	7	Setup	Menu
Tv Audio	8	Up	Up
Tuner	9	Down	Down
Online Music	Guide	Right	Right
Bluetooth	0	Left	Left
Internet Radio	Pre Ch	Enter	Ok
Channel+	Ch +	Vol+	Vol +
Channel-	Ch -	Vol-	Vol -

Original	Sustituto	Original	Sustituto
Power	Power	Page Up	>>
Eco	3D	Page Down	<<
Sleep	Sleep	Green/Movie	Green
CBL/SAT	1	Red/Music	Red
DVD/Blu-ray	2	Blue/Game	Blue
Blu-ray	3	Yellow/Pure	Yellow
Game	4	Info	Info
AUX	5	Option	Options
Media Player	6	Back	Back
iPod/USB	7	Setup	Menu
Tv Audio	8	Up	Up
Tuner	9	Down	Down
Online Music	Guide	Right	Right
Bluetooth	0	Left	Left
Internet Radio	Pre Ch	Enter	Ok
Channel+	Ch +	Vol+	Vol +
Channel-	Ch -	Vol-	Vol -





	Original	Sustituto		Original	Sustituto
	 Mute	 Mute			
	 >> /Tune+	 >>			
	 <</Tune-	 <<			
	 Play	 Play			
	 Pause	 Pause			
	 Quick Select 1	 Shift + 1			
	 Quick Select 2	 Shift + 2			
	 Quick Select 3	 Shift + 3			
	 Quick Select 4	 Shift + 4			
	 Power Zone 2	 Shift + Power			
	 Source Zone 2	 AV			
	 Vol+ Zone 2	 Shift + Vol +			
	 Vol- Zone 2	 Shift + Vol -			

