



















































Original	Sustituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 ↔	 Pre Ch
 Back	 Back
 Menu	 Menu
 Netflix	 Media
 Internet	 Smart
 Ok	 Ok

Original	Sustituto
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Vol+	 Vol +
 Vol-	 Vol -
 P+	 Ch +
 P-	 Ch -
 Mute	 Mute
 i	 Info
 Exit	 Exit
 Source	 AV
 Q.Menu	 D. Menu
 EPG	 Guide
 TXT	 Text
 *	 Format
 */Q	 3D





Original		Sustituto		Original		Sustituto	
	[>]		Options				
	Lang		Dual				
	Subt.		Subt				
	[+]		Shift + Format				
	TV		TV/R				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Rec		Rec				
	Play		Play				
	Stop		Stop				
	Pause		Pause				
	<<		<<				
	>>		>>				

