













































Original	Sustituto	Original	Sustituto
PWR On/Off	 Power	CH/Page+	 Ch +
Mute	 Mute	Audio	 Dual
Info	 Info	CH/Page-	 Ch -
Sleep Timer	 Sleep	1. ?	 1
TV	 Smart	2abc	 2
Video	 AV	3def	 3
Text	 Text	4ghi	 4
Menu	 Menu	5jkl	 5
Display	 +  Shift + Info	6mno	 6
Menu Up	 Up	7pqrm	 7
Menu Down	 Down	8tuv	 8
Menu Right	 Right	9wxyz	 9
Menu Left	 Left	Guide Pilote	 Guide
OK Enter	 Ok	0/10	 0
Exit	 Exit	FAV Pref.	 Pre Ch
Volume+	 Vol +	Red	 Red
Volume-	 Vol -	Green	 Green



Original	Sustituto	Original	Sustituto
Yellow		Yellow	
Blue		Blue	
Freeze		3D	
Dec/Pause		Pause	
Help		D. Menu	
East		Options	
Lang./Rewind		<<	
Radio		TV/R	
H/V Play		Play	
LNB F.Forward		>>	

