







































































Original	Sustituto	Original	Sustituto
	Power		Power
	Source		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	TV		TV/R
	Mute		Mute
	Recall		Pre Ch
	Menu		Menu
	Q.Menu		D. Menu
	World		Media
	Vol+		Vol +
	Vol-		Vol -
	PR+		Ch +
	PR-		Ch -
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Back		Back
	Exit		Exit
	i		Info
	Guide		Guide
	/Music/Photo/Movi		Dual
	[≡]/Text		Text
	*/o		Format





Original	Sustituto
*/o..	3D
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
Lang	List
[≡]..	Subt
[-o-]	Shift + 3D
Rec	Rec
Play	Play
Pause	Pause
Stop	Stop
>>	>>
<<	<<

Original	Sustituto

