






















































































Original	Sustituto	Original	Sustituto
 Power	 Power	 Title/PgUp	 Ch +
 Eject	 Eject	 Prog/PgDn	 Ch -
 1	 1	 Zoom/EPG	 Guide
 2	 2	 SUB-T	 Subt
 3	 3	 TTX	 Text
 4	 4	 PBC/Menu	 Menu
 5	 5	 Audio	 Dual
 6	 6	 Display/Info	 Info
 7	 7	 Exit	 Exit
 8	 8	 Up/CH+	 Up
 9	 9	 Down/CH-	 Down
 0	 0	 Right	 Right
 DVD/DVB	 Smart	 Left	 Left
 Tv/Radio	 TV/R	 OK	 Ok
 Digest	 Format	 Vol+	 Vol +
 Angle/FAV	 Pre Ch	 Vol-	 Vol -
 A-B/Return	 Back	 Goto/List	 List





Original	Sustituto	Original	Sustituto
 Rec	 Rec		
 Stop	 Stop		
 Play	 Play		
 Pause	 Pause		
 <<	 <<		
 >>	 >>		
 I<<	 I<<		
 >>I	 >>I		
 Red/Slow	 Red		
 Green/Step	 Green		
 Yellow/Repeat	 Yellow		
 Blue/Direct	 Blue		
 Setup	 Options		
 USB	 AV		
 Mute	 Mute		
 Video	 3D		

