






































| Original  | Sustituto  |
|---|--|
|  DVD / TV / AV       |  Power  |
|  1                   |  1  |
|  2                   |  2  |
|  3                   |  3  |
|  4                   |  4  |
|  5                   |  5  |
|  6                   |  6  |
|  7                   |  7  |
|  8                   |  8  |
|  9                   |  9  |
|  0                 |  0  |
|  Mute              |  Mute   |
|  Repeat / TV/Radio |  TV/R   |
|  Repeat / TV/Radio |  +  Shift + Text |
|  Exit              |  Exit   |
|  Up / CH+          |  Up   |
|  Up / CH+          |  Ch +   |

| Original   | Sustituto  |
|--|--|
|  Down / CH-   |  Down   |
|  Down / CH-   |  Ch -   |
|  Right / Vol+ |  Right  |
|  Right / Vol+ |  Vol +  |
|  Left / Vol-  |  Left   |
|  Left / Vol-  |  Vol -  |
|  OK           |  Ok   |
|  Pg Up        |  +  Shift + Ch + |
|  Pg Dn        |  +  Shift + Ch - |
|  Title        |  Smart  |
|  Info       |  Info   |
|  Goto / FAV |  Pre Ch   |
|  Audio      |  Dual   |
|  Sub-T      |  Subt   |
|  Zoom / TTX |  Text   |
|  Zoom / TTX |  Eject  |
|  Setup      |  Options  |



