



























Original	Sustituto
 Standby	 Power
 Timer	 AV
 Monitor	 Smart
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Select	 Ok
 Clear	 Exit
 System	 Menu
 Tracking	 Options

Original	Sustituto
 SP/LP	 Format
 P+	 Ch +
 P-	 Ch -
 Record	 Rec
 Play	 Play
 <<	 <<
 Play	 Play
 >>	 >>
 >I/Index	 >>I
 Stop	 Stop
 >I</Still	 3D

