





































Original	Sustituto
 Power	 Power
 SAT	 AV
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Texts	 Smart
 Back	 Back
 Vol +	 Vol +
 Vol -	 Vol -

Original	Sustituto
 Menu	 Menu
 Exit	 Exit
 Guide	 Guide
 CH +	 Ch +
 CH -	 Ch -
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 Page Down	 Shift + Ch -
 Page Up	 Shift + Ch +
 Info	 Info
 Subtitle	 Subt
 Audio	 Dual
 Check	 Shift + Ok
 Red	 Red





Original	Sustituto
	Green
	Yellow
	Blue
	Format
	Sleep
	TV/R
	Text
	Play
	Stop
	Pause
	Rec
	Shift + Text
	Shift + Pause
	<<
	>>
	Shift + Format
	Shift + Play

Original	Sustituto
	I<<
	>>I
	List
	Eject
	Pre Ch

