




| Original   | Sustituto  |
|--|--|
|  Power  |  Power    |
|  Mute   |  Mute     |
|  1      |  1        |
|  2      |  2        |
|  3      |  3        |
|  4      |  4        |
|  5      |  5        |
|  6      |  6        |
|  7      |  7        |
|  8     |  8       |
|  9    |  9      |
|  0    |  0      |
|  Back |  Back   |
|  Fav  |  Pre Ch |
|  Menu |  Menu   |
|  Exit |  Exit   |
|  EPG  |  Guide  |

| Original  | Sustituto  |
|---|--|
|  i             |  Info     |
|  Up            |  Up       |
|  Right         |  Right    |
|  Down          |  Down     |
|  Left          |  Left     |
|  OK / List     |  Ok       |
|  OK / List     |  List     |
|  V +           |  Vol +    |
|  V -           |  Vol -    |
|  TV / R       |  TV/R    |
|  SAT         |  AV     |
|  P +         |  Ch +   |
|  P -         |  Ch -   |
|  Red / F1    |  Red    |
|  Green / F2  |  Green  |
|  Yellow / F3 |  Yellow |
|  Blue / F4   |  Blue   |



